AUTOLINK Telematics Supported Features

√ Supported
X Not tested yet
! Caution, see Notes

NOTES: (1) Connect the AUTOLINK device using the HRN-MCAR-01 directly into the Black RS-232 port.
(2) Blade-AL (64) MUST be used for full connectivity with remote starter functions.
(3) Engine WILL Start
(4) Must enable in the remote start options, Smart Phone Baud Rate to Option #1 (9600)
(5) Connect the AUTOLINK device using the HRN-MCAR-01 and HRN-LLRS-01 with White 4-pin connector. Connect to White data port on the side of the remote start unit.
(6**) NOT RECOMMENDED ON MANUAL TRANSMISSION VEHICLES**
(7) Does not report back run time

Remote Starter Brands	ADS	ADS	ADS	CrimeStopper	CrimeStopper	Compustar	DEI	Fortin
Remote Starter Models	HC3	ADS-CH4 ADS-CH5 ADS-CH7 ADS-F01 ADS-GM10 ADS-GM2 ADS-GM7 ADS-HA6 ADS-HA7 ADS-NI5	ADS-BM1 ADS-BZ1 ADS-BZ2 ADS-BZ3 ADS-BZ4	RS00-G5 RS1-G5 RS3-G5 RS4-G5 RS7-G5	SP-402 SP-502	CM-6200 CM-7200	4X10 5X10	EVO-ALL EVO-ONE
Notes	(1)	(1)	(1,3)	(4,5)	(4,5)	(1,2,3)	(7)	(7)
Basic Functions								
Lock	√	√	√	√	√	√	√	√
Unlock	√	√	√	√	√	√	√	√
Remote Start	√	√	√	√	√ !(6)	√	√ !(6)	√ !(6)
Runtime Extend	√							
Start Confirmation W/ Phone Unlocked	√	√	√	√	√	√	√	√
Start Confirmation W/ Phone Locked	√	√	√	√	√	√	√	√
Runtime Displayed After Remote Start	√	√	√	√	√	√	X	X
Runtime Displayed After App Refresh	√	√	√	√	√	√	X	X
Runtime Display OFF After Stop Command	√	√	√	√	√	√	√	√
Press Stop Button W/ Engine ON	√	√	√	√	√	√	√	√
Press Stop Button W/ Engine OFF	√	√	3 !	√	√	3 !	√	√
Stop Confrimation W/ Phone Unlocked	√	√	√	√	√	√	√	√
Stop Confirmation W/ Phone Locked	√	√	√	√	√	√	√	√
Trunk Release/ Motorized Gate Open	√	√	√	√	√	√	√	√
AUX1	√	√	√	√	√	√	√	√
AUX2	√	√	√	√	√	√	√	√
AUX3	√							
AUX4	√							
STATUS								
Battery Level	√	√	√	√	√	√	√	√
Generic Alarm Notification (W/ Yellow Wire Connected)	√	√	√	√	√	√	√	√
GPS Position	√	√	√	√	√	√	√	√